



KARL ANDERSSON & SÖNER
SINCE 1898

FRONT PANEL

DESIGN SKALA DESIGN / LASSE PETTERSSON LENNART NOTMAN 2005

MONTERINGSANVISNING ASSEMBLY INSTRUCTION

Börja med den vänstra panelen om du ska montera fler FRONT på rad. Karl Andersson & Söner ansvarar ej för upphängningen på vägg.

1. Skruva loss den undre ställisten från panelens baksida.
2. Använd vattenpass och ta reda på vad väggtypen kräver för infästning.
3. Häng på panelen (A) och skjut den åt vänster, ca 40mm.
(B) Kontrollera att den hamnar i rätt läge genom att lyfta den rakt upp. Den skall inte kunna lyftas av listen.
4. Sätt i glasskivan.

Tips! Vill man att glaset ska sitta fast - använd en tunn sträng glassilikon.

Start with the left panel if you should mount more than one FRONT in a row. Karl Andersson & Söner take no responsibility for the mounting on wall.

1. Unscrew the lower steel ledge from the backside of the panel.
 2. Use a water-leveller and suitable screw systems for the wall.
 3. Hang the panel on the ledge (A) and move it to left approx 40mm.
(B) Make sure it is at right position by lifting it up. You should not be able to lift it off.
 4. Put the glass into the groove.
- Tips! use silicon if you want to fasten the glass front into the groove.

