



KARL ANDERSSON & SÖNER
SINCE 1898

RIDÅ EXPONERINGSSYSTEM VÄGG DISPLAY WALL

DESIGN JOEL KARLSSON / KROOK & TJÄDER DESIGN 2010

MONTERINGSANVISNING ASSEMBLY INSTRUCTION

Börja med den vänstra panelen om du ska montera fler RIDÅ på rad. Karl Andersson & Söner ansvarar ej för upphängningen på vägg.


1. För paneler med bredd 371mm välj vilket håll den ska placeras - liggande eller stående. Skruva loss den nedre ställisten från panelens baksida.
3. Använd vattenpass och ta reda på vad väggtypen kräver för infästning.
4. Häng på panelen (A) och skjut den åt vänster, ca 40mm.

(B) Kontrollera att den hamnat i rätt läge genom att lyfta den rakt upp. Den skall inte kunna lyftas av listen.

Start with the left panel if you should mount more than one RIDÅ in a row. Karl Andersson & Söner take no responsibility for the mounting on wall.

1. Panels with width 371mm, choose if it should hang vertical or horizontal. Unscrew the lower steel ledge from the backside of the panel.
2. Use a water-leveller and suitable screw systems for the wall.
3. Hang the panel on the ledge (A) and move it to left, approx 40mm.

(B) Make sure it is at right position by lifting it up. You should not be able to lift it off.



Lister för horisontell placering, endast för bredd 371mm.
Ledges for horizontal placement, only for width 371mm.